

TABLE OF CONTENTS

Chapter 1: Introduction

Welcome.....	1-1
Parts of the Analyzer	1-1
Powering Up the Analyzer.....	1-3
Using the Analyzer Menus.....	1-3

Chapter 2: Basic Functions

Run a Program.....	2-1
Select a Program.....	2-2
Probe	2-2

Chapter 3: Programs

Computer-Analyzer Program Transfers	3-2
Analyzer-DynaCard Program Transfers	3-4
DynaCard Utilities.....	3-6
Analyzer Memory Utilities	3-7
Program Data.....	3-9
Quick Reload Feature.....	3-12

Chapter 4: Utilities

Analyzer Counters.....	4-1
Autolearn Functions	4-2
Error Logging	4-5

Chapter 5: Settings

Formats

Error Tone	5-1
Symbolic Display.....	5-2
Language.....	5-2
Clock Functions	5-3
Unit ID	5-3
Volume	5-4
Contrast	5-4

Restrictions

DynaCard Menu Lock.....	5-4
Powerup Execution Setting.....	5-5
Multiple Programs.....	5-5
Keyswitch Setup	5-6

Configurations

Exceptions Restart Function	5-6
Variable Memory.....	5-6

Chapter 6: Ports

Serial Ports	6-1
Control Ports	6-3
Test Points	6-4

Chapter 7: Troubleshooting

Contacting Technical Support.....	7-1
Return Materials Authorization Policy.....	7-1
Recommended Maintenance	7-1
Analyzer Major Components	7-2
RESET Function.....	7-3
Diagnostic Guide	7-3
Self-Diagnostics Tests	7-7
Limited Warranty	7-10

Appendix A: Specifications

Specification Details	A-1
Calibration Notice.....	A-2

Appendix B: EPROM Software

Software History.....	B-1
Upgrade Procedure	B-5